



How to use Roommate's **Boost** Feature

If you are using the room out-of-hours and wish to temporarily Boost the temperature:

Simply scan the Roommate QR code and press '**Boost**'

BOOST TEMPERATURE FOR 1 HR

The room will then quickly heat up for an hour. Feel free to scan and Boost again if you are staying longer.

Thank you for saving energy and carbon with Roommate, powered by EcoSync